

1-800-375-0605 Option 8 for 24/7 Service





BETASEAL™ X2500 PLUS (A+B)

Glass Bonding Systems

BETASEAL™ X2500 PLUS (A+B) is a two-component polyurethane adhesive for glass and structural bonding applications. BETASEAL™ X2500 PLUS (A+B) is a high-viscosity, non conductive adhesive, which cures almost independently of moisture.

BETASEAL™ X2500 Plus has a 1 hour Safe-Drive-Away-Time, crash tested to FMVSS 212 specification with twin airbags.

All DuPont Adhesives products are primarily developed in co-operation with the automobile manufacturers, according to their needs and their specifications, they are approved for the specific applications as defined by the customer. The use of the product other than approved application must be released in written form by the Technical Service of DuPont Adhesives.

Unless specified otherwise test are conducted at 23°C/50% relative humidity.

Component A

Basis, Component A	Polyurethane -
	prepolymers
Colour, Component A	Black
Density, Component A	1.25 - 1.29 g/cm ³
Extrusion Viscosity, Component A	10 - 26 ^[1] g/mir
[1]: At 23°C, 4mm nozzle/ 4bar	

Component B

Basis, Component B	Polyol compound -
Colour, Component B	Black
Density, Component B	1.19 - 1.23 g/cm³
Extrusion Viscosity, Component B	10 - 30 ^[1] g/min
[1]: At 23°C, 4mm nozzle/ 4bar	

Product information

Solid content ≥S	96	%
------------------	----	---

Uncured Properties

Sagging		30 ^[2] °

[2]: On vertical wall tilting (maximum).

Application technique

Working time	6 - 12 min
Processing temperature	15 - 40 °C

Revised: 2021-09-28 Page: 1 of 3



BETASEAL™ X2500 PLUS (A+B)

Glass Bonding Systems

Cured properties

-40 - 100 °C Temperature stability Volume resistivity 1E10 Ohm.cm

Typical mechanical properties

5^[3] MPa Stress at break ISO 1798 Strain at break 150 % ISO 1798 Shear modulus ≥2.5 MPa

[3]: After 24 hours

Storage and stability

9^[4] months Shelf life

[4]: Shelf life is assured at +5°C to +25°C in unopened containers. Short time storage temperatures: 0°C to +40°C

Characteristics

Compatibility Glass, Paint

Additional Information

Adhesives

Bonding surface preparation

All bonding surfaces must be free of impurities (dirt, dust, water, oil, grease, release agent and similar contaminants). In general surfaces should be primed. Verify compatibility or consult our technical service department.

Application Equipment

BETASEAL X2500 Plus (A + B) is preferably mixed dynamically. A special dynamic mixing head is included with every set.

The BETAGUN (TM) electro-mechanical processing device is an application gun that was developed for the processing of BETASEAL X2500 Plus (A + B) sets and ensures optimal processing.

Cleaning

Uncured adhesive residues can easily be removed with BETACLEAN™ 3500. Hardened adhesive residues can only be removed mechanically. Immerse equipment in BETACLEAN™ 3000.

Revised: 2021-09-28 Page: 2 of 3

dupont.com









BETASEAL™ X2500 PLUS (A+B)

Glass Bonding Systems

Revised: 2021-09-28 Page: 3 of 3

dupont.com

The information set forth herein is furnished free of charge, is based on technical data that DuPont believes to be reliable, and represents typical values that fall within the normal range of properties. This information relates only to the specific material designated and may not be valid for such material used in combination with other materials or in other processes. It is intended for use by persons having technical skill, at their own discretion and risk. This information should not be used to establish specification limits nor used alone as the basis of design. Handling precaution information is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards and comply with applicable law. Since conditions of product use and disposal are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any product, evaluation under end-use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate or a recommendation to infringe on patents.

CAUTION: Do not use DuPont materials in medical applications involving implantation in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract or other acknowledgement that is consistent with the DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your DuPont representative.

DuPont's sole warranty is that our products will meet our standard sales specifications in effect at the time of shipment. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, DUPONT SPECIFICALLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR NON-INFRINGEMENT. DUPONT DISCLAIMS LIABILITY FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

DuPont[™], the DuPont Oval Logo, and all trademarks and service marks denoted with [™], SM or ® are owned by affiliates of DuPont de Nemours, Inc. unless otherwise noted. © 2021 DuPont. All rights reserved.





