

Two component, Translucent Silicone mold-making material

## KE-1321/CAT-1321S

### Features

- Addition cure system
- Good durability with polyurethane resins
- Low viscosity
- Moderate tensile strength
- Low linear shrinkage
- Room temperature cure or heat cure to shorten the curing time

### Applications

Mold-making of intricate design models etc.

### Typical Properties

Item	Unit		KE-1321 Base	CAT-1321S Curing agent
Appearance			Translucent Liquid	Transparent Liquid
Viscosity	Pa·s	mm <sup>2</sup> /s	67	670
Mixing ratio	Wt%		100	10
Cure type			Addition Cure	
Working time at 23°C	min.		80	
Curing time at 23°C	Hours		24	
Density at 23°C	g/cm <sup>3</sup>		1.08	
Hardness	Type-A		40	
Elongation at break	%		290	
Tensile strength	MPa		6.2	
Tear strength	kN/m		19	
Linear shrinkage	%		< 0.1	
Catalyst Alternatives			CAT-1321L (Longer pot life)	

Not specification values

**Packing:** KE-1321            Net weight 20kg pail  
                   CAT-1321S        Net weight 1kg can

### How to use

#### 1) Preparation

First, master patterns are prepared. They can be of materials which have a surface firm enough to be painted with RTV: such as wood, plastic, metal, clay, etc. However, some materials and coatings on master patterns can inhibit cure, and it is suggested that a pretest with a few grams of catalysed rubber be carried out. Barrier Coat NO.6 can be painted to the surface of the master pattern to prevent cure inhibition.

#### 2) Measurement

Pour the required quantity of KE-1321 into a mixing vessel. Foaming to 4 or 5 times the original volume may occur in the early stage of the de-aeration process suggested below, so a vessel of sufficient size should be employed.

### 3) Curing agent addition

10% by weight of curing agent CAT-1321S is added to KE-1321.

### 4) Applying the mixture

Mixing should be carried out as soon as the curing agent CAT-1321S has been added. In general, a spatula or a mixer will help to ensure even dispersion and subsequent uniform cure. When catalysed, KE-1321 increases in viscosity, therefore, pouring should be carried out as soon as possible after the de-aeration process.

### 5) De-aeration

De-air thoroughly with vacuuming equipment until the mix becomes free of air bubbles.

Under vacuum, KE-1321 will rapidly froth and increase in volume. The bubbles will then collapse, and KE-1321 will regain its original level.

### 6) Pouring the mold

If the master pattern contains deep crevices and undercuts, in order to prevent air entrapment slowly pour KE-1321 into a corner of the frame and allow it to flow around the pattern.

### 7) Curing

Standard curing condition of KE-1321/CAT-1321S

Room temperature cure: At 23°C for 24hrs

## **Storage condition**

KE-1321 and CAT-1321S should be stored at between 1 to 25°C. Avoid direct sunlight.

## **Handling precautions – Curing inhibition -**

An Addition cure Silicone rubber may not cure on surfaces where it comes in contact with certain types of substances. It may fail to cure entirely if certain substances have been mixed into the rubber. This phenomenon, which is known as “curing inhibition” occurs because the substances inhibits the catalytic function of the RTV silicone rubber.

Possible cure inhibitors are substances which contain sulfur, phosphorus, nitrogen compounds, water and organometallic salts.

Specific examples of curing inhibitors ;

- Organic rubber (natural rubber and synthetic rubbers such as chloroprene rubber, nitrile rubber and EPDM)
- Soft polyvinyl chloride resin
- Amine-hardening Epoxy resin
- Isocyanates of urethane resin
- Rubber clay and oil clay
- Condensation cure RTV Silicone rubber (KE-45, KE-66, KE-12, KE-17 and KE-1414 etc)
- Some adhesive tape bonding agents, adhesives, paints (such as polyester paints), waxes, solder fluxes and pine resin

## Safety and hygiene

Uncured KE-1321/CAT-1321S may irritate skin and mucous membranes, so avoid eye contact and prolonged skin contact. In case of accidental eye contact, flush with water for at least 15 minutes and see a physician. In case of skin contact, immediately wipe off with a dry cloth and wash with soapy water. Contact lens wearers should exercise adequate caution; if uncured KE-1321/CAT-1321S enters the eyes, the contact lens may become bonded to the eye.

When using, be careful not to rub the eyes with the hands. Please take appropriate precautions such as wearing safety glasses.

Make sure that work area is well ventilated. Be careful not to inhale vapors from the products used.

Keep out of reach of children.

For more information, please read the Material Safety Data Sheet (MSDS). You can receive an MSDS from our Sales Department.

## Contact us

Shin-Etsu Chemical Co., Ltd.

Silicone Division, Sales and Marketing Department IV

6-1, Ohtemachi 2-chome, Chiyoda-ku, Tokyo, Japan

TEL:+81-3-3246-5152, FAX: +81-3-3246-5362

<http://www.shinetsu.co.jp>

Shin-Etsu Silicone International Trading (Shanghai) Co., Ltd

29F Junyao International Plaza, No.789, Zhao Jia Bang Road, Shanghai 200320

TEL:+86--21-6443-5550, FAX:+86-21-6443-5868

<http://www.shinetsu.com.cn>

Shin-Etsu Silicone Taiwan Co., Ltd.

Hung Kuo Building 11F-D, No.167, Tun Hua N.RD., Taipei, 10549, Taiwan, R.O.C.

TEL:+886-2-2715-0055, FAX:+886-2-2715-0066

<http://www.shinetsu.com.tw>

Shin-Etsu Silicone Korea Co., Ltd.

Danam B/D 9F, Namdaemunno5(O)-Ga, Jung-Gu, Seoul 100-704 Korea

TEL:+82-2-755-9691, FAX:+82-2-775-9690

<http://www.shinetsu.net>

Shin-Etsu Singapore Pte.Ltd.

4 Shenton Way #10-03/06 SGX Centre II Singapore 06807

TEL:+65-6743-7277, FAX:+65-6743+7477

<http://www.shinetsu.com.sg>

Shin-Etsu Silicones (Thailand) Ltd.

7th Floor, Harindhorn Tower, 54 North Sathorn Road, Bangkok 10500 Thailand

TEL:+66-2-632-2941, FAX:+66-2-632-2945

Shin-Etsu Silicones of America, Inc.

1150 Damar Drive, Akron OH 44305 U.S.A.

TEL:+1-330-630-9860, FAX:+1-330-630-9855

<http://www.shinetsusilicones.com>

Shin-Etsu Silicones Europe B.V.

Bolderweg 32, 1332 AV Almere, The Netherlands

TEL:+31-36-5493170, FAX:+31-36-5326459

## Warranty

The data and information presented in this catalog may not be relied upon to represent standard values. Shin-Etsu reserves the right to change such data and information, in whole or in part, in this catalog, including product performance standards and specifications without notice.

Users are solely responsible for making preliminary tests to determine the suitability of products for their intended use. Statements concerning possible or suggested uses made herein may not be relied upon, or be construed, as a guaranty of no patent infringement.

The silicone products described herein have been designed, manufactured and developed solely for general industrial use only; such silicone products are not designed for, intended for use as, or suitable for, medical, surgical or other particular purposes. Users have the sole responsibility and obligation to determine the suitability of the silicone products described herein for any application, to make preliminary tests, and to confirm the safety of such products for their use.

Users must never use the silicone products described herein for the purpose of implantation into the human body and /or injection into humans.

Users are solely responsible for exporting or importing the silicone products described herein, and complying with all applicable laws, regulations, and rules relating to the use of such products. Shin-Etsu recommends checking each pertinent country's laws, regulations, and rules in advance, when exporting or importing, and before using, the products.

Please contact Shin-Etsu before reproducing any part of this catalog.

Copyright belongs to Shin-Etsu Chemical Co., Ltd.

D4-2009/8/25

Distributed by:  
Rudolph Bros. & Co.  
PO Box 425, Canal Winchester, OH 43110  
Phone: 614-833-0707  
Fax: 800-600-9508  
e-mail: [rbcsupport@rudbro.com](mailto:rbcsupport@rudbro.com)  
[www.rudbro.com](http://www.rudbro.com)